

Installation Guide

Steps to Install Coiled Pin (PTCOILPIN12)

For 1/2" Square Tubular Balusters



<p>1. Drill hole into substrate. Hole diameter: 13/32" Depth: 1" to 1 1/4"</p>	
<p>2. Insert coiled pin into hole.</p>	
<p>3. Place baluster over coiled pin, center baluster, then hammer into place until baluster is level with base of substrate.</p>	